

**APPLICATION INSTRUCTIONS FOR USING
GLASS MARKING COMPOUND
with
SELECTAMARK STENCILS**

PREPARATION

- Ensure surface of item is clean and dry.
- Peel off wide strip of backing paper from stencil (leave narrow strip to facilitate removal of stencil from item after marking).
- Apply stencil to item, rubbing down firmly with backing paper - especially around dot-matrix holes - to ensure there are no air bubbles and the stencil adheres firmly to the surface.

PROCEDURES FOR MARKING GLASS ITEMS

- Compound should be used for marking ONLY smooth glass surfaces.
- Shake tube vigorously.
- Cut off sealed tip of tube.
- Apply a little compound to the white plastic spreader provided.
- Spread the compound into the dot-matrix holes, ensuring each is **completely filled** with the blue coloured compound.
- After approx 4 minutes, remove any excess compound from stencil by dabbing with a clean paper kitchen towel, then carefully peel off stencil.
- Wipe the mark immediately with a clean cloth and water.
- The resultant mark on glass will be white/grey in colour, with a 'sanded' appearance.
- On certain glass surfaces it may be necessary to leave the compound for longer than 4 minutes to obtain a 'whiter' or more solid mark.

Each tube of Marking Compound contains sufficient to mark approx 20 stencils – we provide more than sufficient to complete your marking as per the stencils ordered. Once opened the compound will dry out or harden in a few months. Unopened, the compound has a shelf life of at least 6 months when kept in a cool, dark place.

Have you read the detailed instructions above? If followed carefully, you will have a successful marking each time. Remember that the mark is permanent, so any mistake cannot be altered.

IMPORTANT NOTES

- Do not allow children to use the marking compounds.
- Keep the tubes of compound in a cool place and preferably in a locked cupboard.
- After use, stencils and compounds should be disposed of carefully.
- DO NOT EAT, DRINK OR SMOKE WHEN USING ANY COMPOUND.
- Protect eyes and hands when using Marking Compounds.
- If the Compound comes into contact with skin, it should be washed off with soap and warm water or an alcohol swab as soon as possible.
- If the Compound comes into contact with eyes do NOT rub. Rinse immediately with plenty of water and obtain medical attention, showing Compound container to medical staff.
- If Compound is swallowed, seek medical advice immediately, showing Compound container to medical staff.