

APPLICATION PROCEDURE USING
WHITE COMPOUND in GLASS BOTTLE
using with
SUPERMARK LABELS

(White compound in BOTTLES is weaker than the Blue compound in the small tubes and is normally therefore recommended only for use on black/dark plastic or painted surfaces).

Please read before commencing marking

The SELECTAMARK system is very simple to carry out if the instructions are followed. All items to be marked should be clean and dry, and best results are on flat, smooth surfaces. To ensure surface to which label is to be applied is free of dirt or residue, we suggest wiping with a clean cloth soaked with alcohol and then allowing time to DRY THOROUGHLY.

USING WITH SUPERMARK LABELS

- Remove backing paper from label and apply label to surface.
- Make sure the label is firmly in place on the item to be marked by rubbing down firmly using the backing paper removed, or a sheet of clean white printing paper. Press down hard around the holes and label edges to expel all air.
- Squeeze some compound onto the small plastic spreader provided and spread the compound across and into the holes, ensuring all the holes are filled with the white compound. **NOTE: Do NOT apply too much compound - only sufficient to fill the holes. Remove any excess compound around the mark or on other areas of the label using the spreader.**
- Leave for 15-30 seconds then remove the protective overlay, by carefully lifting from the top where it is coloured red (**from the top right edge with small labels**). Take care not to damage the label when lifting the overlay
- **DO NOT TOUCH MARK OR LABEL FOR AT LEAST 24 HOURS** (mark will feel dry to the touch after approx 1 hour but will take about 8 hours to harden).

IMPORTANT NOTES

- Do not allow children to use the marking compounds.
- Keep the compound in a cool place and preferably in a locked cupboard.
- After use, label overlays and compounds should be disposed of carefully.
- **DO NOT EAT, DRINK OR SMOKE WHEN USING ANY COMPOUND.**
- Protect eyes and hands when using Marking Compounds.
- If the Compound comes into contact with skin, it should be washed off with soap and warm water or an alcohol swab as soon as possible.
- If the Compound comes into contact with eyes do NOT rub. Rinse immediately with plenty of water and obtain medical attention, showing Compound container to medical staff.
- If Compound is swallowed, do NOT induce vomiting. – Drink water and seek medical advice immediately, showing Compound container to medical staff.

Each Bottle of Marking Compound contains sufficient to mark approx 50 labels – we provide more than sufficient to complete your marking as per the labels ordered. The compound has a shelf life of 24 months when unopened and kept in a cool, dark place, with the top firmly closed. Once opened, the shelf life is approx 12 months. Make sure you replace the cap after each use.

Have you read the detailed instructions above? If followed carefully, you will have a successful marking each time. Remember that the mark is permanent, so any mistake cannot be altered.